

**Anhänger zusammenfalten:**

Verdeckfront abnehmen. Rückenlehne nach vorne kippen (eventuell müssen die Taschen abgenommen werden).

Rändelschrauben wieder ins Gewinde schrauben.

Räder abnehmen und in den Anhänger legen.  
(Räder demontieren, siehe Seite 13)

Schiebebügel abmontieren und in den Gepäckraum legen.

Rändelschrauben, die Front- und Überrollbügel zusammenhalten, heraus-schrauben und Überrollbügel herunterklappen.

Rändelschrauben wieder in das Gewinde im Frontbügel einsetzen.

Deichsel und Vorderrad verpacken, danach Verdeckfront darüberlegen.

**Wichtig!** Wenn der Anhänger auf einem Autodach transportiert werden soll, muß das Kunststoffvorderfenster sicher festgemacht werden, damit es sich während der Fahrt nicht löst.

**Collapsing the trailer:**

Remove the hood. Tip the backrest forwards. It may be necessary to remove the pockets.

Replace the screw knobs in their threaded holes.

Remove the wheels and place inside the trailer.  
(Demounting the wheels, see page 13)

Remove the pushbar and place in the luggage compartment.

Unscrew screw knobs joining the front and rollover bars, and fold down the rollover bar.

Rescrew the screw knobs into the front bar.

See to the tow bar and front wheel before replacing the hood.

**Important!** If the trailer is to be transported on a car top, the plastic front window must be fixed, so that it does not blow loose while under way.